

EN User Guide for Brilagi Christmas lights

Dear customer, thank you for purchasing our product. Please carefully read and abide by the following instructions to ensure that this product is used safely and to your complete satisfaction. This will also help avoid any improper use or damage. Prevent any unskilled handling of the device and always follow the principles of use for electrical appliances. Store these instructions in a safe place.

Description

• power supply: 230V AC • -20°C to +50°C • protection class: IP44 (outdoor and indoor use) • 8 light modes (flashing, light blending, dimming, etc.) • memory function - after switching on the last used light mode is activated • timer 6h/18h - after 6h from switching on it automatically switches off and on again after 18h • indoor and outdoor use

Warning

- 1. First unpack the lights from the box and unwind them fully before plugging them into a power outlet and turning them on. This prevents any excessive overheating and possible fire.
- 2. These lights heat up when in use. Therefore, do not place them near any other heat sources and do not cover them.
- 3. Do not use the lights if they are damaged in any way, including if the cable is damaged or if there has been a short circuit or high-voltage surge.
- 4. Use only the power adapter supplied. Never connect the lights or any part of the lights to the electricity mains or to any other product.
- 5. The product complies with protection class IP44 and is suitable for outdoor use.
- 6. To clean the lights, use a damp cloth and always disconnect from the electricity mains first. Leave the lights to dry completely before using them.
- 7. Do not tamper with the wiring, as this could result in a short circuit, fire, or injury.
- 8. Disconnect the lights from the electricity mains when not in use.
- 9. This product is not a toy! Keep out of reach of children.
- 10. Protect the environment. When no longer usable, dispose of the product at the designed collection point. Do not discard with normal household waste.
- 11. The product should only be used by adults. Avoid proximity to or contact with home and computer electronics.

Light/blinking modes: Combinations, waves, sequence, slow light up, quick blinking, slow fade, lightning, steady on. Modes are switched by the button on the control. Integrated memory chip ensures the last used mode is activated after the lights are turned on.

Timer automatically turns the lights on and off. Turn it on by long pressing the button on the power adapter. Timer activated is signalized by the light on the button. The timer works as follows. After activation, the lights are turned on for six hours. Then the lights are turned off for eighteen hours and this way all the time until you turn the timer off.