

BRILAGI



USER MANUAL



Manufacturer / Producer:
IMMAX, Pohoří 703, 742 85, Vřesina, Czech Republic, EU
Made in P.R.C.

Distributor:
Donoci s. r. o., Pražská 2532/4, 678 01 Blansko, Czech Republic, EU

TECHNICAL SPECIFICATIONS:

Protocol: Wi-Fi
Frequency: 2400 MHz ~ 2483.5 MHz
Maximum RF output power: WiFi: 20dBm

DOWNLOAD IMMAX NEO PRO AND REGISTRATION


Scan the QR code and download the Immax NEO PRO application.



Or find and install the Immax NEO PRO app in the App Store or Google Play.

- Launch the Immax NEO PRO application and click on “Register” and create your own account.

- If you have finished registration, log in to your account.



Possibility to add via Bluetooth

Connect your mobile to your Wi-Fi router, and use the wall switch to control On and Off circle for 5 times, the light will twinkle again as to factory state, click “+” in the upper right corner of the homepage or click “Add Device”.

Turn on the Bluetooth on your mobile: The app will ask you to turn on the Bluetooth on your mobile, and then you choose the device to add.

Enter your Wi-Fi name and Wi-Fi password, it will connect to the network automatically.

Do not turn on the Bluetooth

Select “LED light - WiFi”, enter the Wi-Fi password, and make sure the LED is blinking rapidly, if not, use the wall switch to control On and Off circle for 5 times, and the light will twinkle again as to factory state, and then wait it will connect automatically.

SAFETY INFORMATION

CAUTION: Keep out of reach of children. This product contains small parts, which may cause suffocation or injury if swallowed.

WARNING: Every battery has the potential to leak harmful chemicals that can damage skin, clothing, or the area where the battery is stored. To avoid the risk of injury, do not allow any substance from the battery to come into contact with the eyes or skin. Every battery may burst or even explode if exposed to fire or other forms of excessive heat. Take care when handling the batteries. To reduce the risk of injury from mishandling the batteries, take the following precautions:

- Do not use different brands and types of batteries in the same device
- When replacing the batteries, always replace all the batteries in the device
- Do not use rechargeable or reusable batteries.
- Do not allow children to insert batteries without supervision.
- Follow the battery manufacturer's instructions for proper battery handling and disposal.

CAUTION: The product and batteries should be disposed of at a recycling center. Do not dispose of them with normal household waste.

CAUTION: To ensure safe use of the product, wires must be brought to the installation site according to valid regulations. The installation must only be carried out by an individual with the appropriate certification in the field of electronics. During installation or when a fault is detected, the power cable must always be disconnected from the socket (in the case of direct connection, the relevant circuit breaker must be switched off). Improper installation can damage the product and cause injury.

CAUTION: Do not disassemble the product, electric shock may occur.

CAUTION: Use only the original power adapter provided with the product. Do not operate the device if the power cord shows signs of damage. **CAUTION:** Follow the instructions in the enclosed manual.

MAINTENANCE

Protect the device from contamination and soiling. Wipe the device with a soft cloth, do not use rough or coarse materials.

DO NOT USE solvents or other aggressive cleaners or chemicals.

A Declaration of Conformity has been issued for this product. More information can be found at www.immax.cz

